




## SECTION 4 ARM, BLOWER & EXTRACTION

### DOWNDRAFT WORK TABLE (ON REQUEST ONLY)

#### DESCRIPTION

- The cover panels provide better suction where the work takes place.
- Table size can be customized upon client request.
- Table can be connected to a fan for evacuation or a filtration unit to recycle air for energy savings.
- Slats are installed for easy replacement due to wear and tear. Spare slats available on demand.
- Slats and their support are not painted to provide a good electrical contact.
- A clip is available to connect the plasma grounding.

**1 YEAR  
WARRANTY  
ON PARTS**



#### OPTIONAL DRAWERS

- Dust and cutting debris can be easily removed using the drawers, so the inside of the table can be cleaned without removing the slats.

